



REVOLT X STAND-ON

ZERO-TURN MOWER OWNER'S OPERATOR SERVICE MANUAL

For additional information, please see us at

www.badboycountry.com

Disclaimer

This document is based on information available at the time of its publication. While efforts have been made to ensure accuracy, the information contained herein does not purport to cover all details or variations, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all systems. Bad Boy Mowers, LLC assumes no obligation to notify holders of this document of any changes made subsequently.

Bad Boy Mowers, LLC makes no representation or warranty, express, implied, or statutory, regarding the accuracy, completeness, sufficiency, or usefulness of the information contained herein, and assumes no liability arising from its use. No warranties of merchantability or fitness for a particular purpose shall apply. This disclaimer applies solely to the information contained in this document and does not affect or limit any separate written warranty that may apply to the product itself. In no event shall Bad Boy Mowers, LLC be liable for any direct, indirect, incidental, special, consequential, or punitive damages, including but not limited to loss of profits, loss of use, or damages arising from reliance on the information contained in this document, whether based in contract, tort, strict liability, or otherwise, even if advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

Read and Understand



Read and follow all instructions and safety precautions in this manual and all other manuals for products associated with this machine as well as in all on-product warning decals. Failure to do so could result in serious injury or death, or property damage. Contact your Bad Boy Mowers, LLC dealer if any of your manuals are missing or illegible or you have questions.

Preface

This manual is intended for use with the following mower models.

BRVX61385KA	BRVX72385KA	BRVX6140EVG	BRVX7240EVG	BRVX54EVO781
-------------	-------------	-------------	-------------	--------------

Revision History

Issue	Date	Reasons For Change
Rev A	9/8/26	Model Year change over

BASIC INFORMATION	1-1
Machine Information	1-1
Model and Serial Number	1-1
QR Code	1-1
Parts and Service	1-1
Warranty	1-1
Warranty Registration	1-1
Evaporative Emission Control Warranty Statement	1-1
Bad Boy Support	1-2
Specifications	1-3
Torque Specifications	1-4
SAFETY	2-1
Safety Symbols	2-1
Machine Safety Guidelines	2-1
Machine Decals	2-1
Personal Protection Equipment (PPE)	2-3
Hearing Protection	2-3
Eye Protection	2-3
Foot Protection	2-3
Hand Protection	2-3
Clothing	2-3
General Operation	2-3
Safety Interlock System	2-4
Fueling	2-4
Slope Operation and Guide	2-5
Children	2-5
Service	2-5
Environmental	2-6
Battery	2-6
Transporting	2-6
CONTROLS	3-1
Machine Overview	3-1
Control Panel	3-2
PRE-OPERATION	4-1
Fuel	4-1
Fuel Shutoff	4-1
Fueling	4-1
Control Arm Stop	4-1
Platform Pad	4-2
Deck Height	4-2
Safety Interlock System	4-2
OPERATION	5-1
Starting the Machine	5-1
Control Lever Arms	5-2
PTO Switch	5-2

Troubleshooting	5-3
Starting / No-Start	5-3
Engine Issues	5-4
Cutting Quality	5-5
Blades Will Not Engage	5-6
Drive and Steering Issues	5-7
Electrical Issues	5-7
Excessive Vibration or Unusual Noise	5-8
Choosing the Right Blade	5-9
Storage	5-9

MAINTENANCE	6-1
Maintenance Schedule	6-1
Lubrication	6-2
Debris Removal	6-3
Hydrostatic System	6-3
Engine Oil	6-4
Battery	6-4
Blades	6-4

SERVICE	7-1
Service Schedule	7-1
Commonly Used Parts	7-2
Blades	7-2
Belts and Filters	7-2
Engine Filters and Spark Plug	7-2
Oils	7-2
Hydrostatic System	7-3
Fluid Volume and Level	7-3
Fluid Change Procedure	7-4
Purge Procedure	7-4
Transaxle Bypass	7-4
Tracking Adjustment	7-5
Pump Belt Adjustment	7-5
Engine	7-6
Engine Oil	7-6
Engine Oil Filter	7-7
Fuel Filter	7-7
Air Cleaner	7-7
Spark Plug	7-8
Electrical System	7-8
Fuses	7-9
Relay-Controlled Interlocks	7-9
Starter Signal Solenoid	7-9
Battery	7-9
Wheels	7-10
Front Caster	7-10
Wheel Lugs	7-10
Lubrication	7-11

Cutting Deck	7-11
Deck Belt Removal	7-11
Deck Belt Installation	7-12
Deck Belt Tension Adjustment	7-12
Leveling the Deck	7-13
Blade Removal	7-14
Decals	7-14

TRANSPORTING 8-1

Loading	8-1
Unloading	8-1
Moving Inoperable Machine	8-1

WARRANTY 9-1

SECTION 1

BASIC INFORMATION

Machine Information

Congratulations on the purchase of your new Bad Boy Revolt X, engineered and built to deliver a superior cut every time! The purpose of this manual is to assist operators in maintaining and operating the machine. The information and instructions in this manual can help you enjoy many years of performance from your new Bad Boy. Also, check out our website to learn more about the Bad Boy family at www.badboycountry.com.

Model and Serial Number



Figure 1: Bad Boy Product Decal

Your machine model and serial numbers are printed on the decal located underneath the kneepad and the crossbar under the control panel. The entire alphanumeric code is your serial number. To find your model number, leave the last eight digits off of the serial number. Record the serial number information here to have it ready when ordering parts.

Serial Number: _____

Date of Purchase: _____

Dealer Information: _____

QR Code

Scan the QR code located on your machine's serial number decal using your smartphone camera to access your MyBadBoy owner portal.

Once your machine is registered, your MyBadBoy portal gives you access to the following resources:

- Owner information
- Dealer information
- Operator's manual
- Mr. Know It All — troubleshooting, FAQs, and best practices
- Maintenance information
- Shop Bad Boy

Parts and Service

Bad Boy recommends using genuine Bad Boy replacement parts on your mower. Replacement parts are available through your local Bad Boy dealer or at www.badboycountry.com. When ordering parts, please have your model and serial number ready as recorded above.

Routine service such as changing fluids and replacing filters and belts can be performed following the "Service Schedule". For all other service and repairs, contact your authorized Bad Boy dealer.

All warranty repair and service must be handled through your authorized Bad Boy dealer. To locate the nearest dealer, go to www.badboycountry.com and click on "FIND A DEALER."

Warranty

Warranty Registration

The warranty registration must be completed within 30 days of purchase to validate your warranty. As a new equipment owner, it is your responsibility to ensure warranty registration is completed.

Purchased through an authorized Bad Boy dealer:

Warranty registration should be completed by your selling dealer at the time of delivery. Please confirm registration has been completed with your dealer by scanning your QR code on the serial number decal.

The warranty is nontransferable.

Evaporative Emission Control Warranty Statement

Federal Evaporative Emission Control Warranty: Your Warranty Rights and Obligations, the Environmental Protection Agency (EPA), and Bad Boy Mowers, LLC are pleased to explain the evaporative emission control system's warranty on your 2027 equipment. New equipment that uses spark ignition engines for off-road use must meet stringent anti-smog standards. The evaporative emission control system on your equipment is designed, built, and equipped so it conforms at the time of sale to the ultimate purchaser with the requirements of 40 CFR 1060. The evaporative emission control system is free from

BASIC INFORMATION

defects in materials and workmanship that may keep it from meeting said requirements. Bad Boy Mowers, LLC must warrant the evaporative emission control system on your equipment for 2 years provided there has been no abuse, neglect, or improper maintenance. If an evaporative emission control system component does fail in a manner that would cause the equipment to no longer meet the requirements of 40 CFR 1060 within the first 2 years, Bad Boy Mowers, LLC will replace the defective component. Your evaporative emission control system may include parts such as fuel tanks, fuel lines, carbon canisters, fuel caps, valves, vapor hoses, clamps, or connectors.

Bad Boy Support

Bad Boy Mowers is committed to keeping you up and running. For technical support, warranty questions, or parts, reach out using the contact information below.

Technical Support	technicalsupport@badboycountry.com
Warranty	warranty@badboycountry.com
Parts	partsdept@badboycountry.com

Specifications

The following specifications apply to all configurations unless otherwise noted. Specifications that vary by cutting width are listed separately. Use the table at the end of this section to identify your unit's cutting width, engine, and transaxle based on your model number.

Height	45.5 in	Fuel Capacity	13 gal
Cutting Height	2 - 5 in	Deck Metal Thickness	3/16 in

	54 in	61 in	72 in
Weight (lbs)	1,199	1,250	1,318
Length (in)	70	45.5	72.5
Cutting Width (in)	54	61	72
Chute Width, Up (in)	56.5	63.2	73.8
Chute Width, Down (in)	68.5	75.5	85.9

Tires

Front Tire Size	13x6.50-6
Rear Tire Size	24" VPO
Front Tire Pressure	12 psi
Rear Tire Pressure	N/A

SKU	Cutting Width	Engine	Transaxle
BRVX61385KA	61 in	Kawasaki FX1000-EFI	16 cu in/18 cu in
BRVX72385KA	72 in	Kawasaki FX1000-EFI	
BRVX6140EVG	61 in	Vanguard 40HP	
BRVX7240EVG	72 in	Vanguard 40HP	
BRVX54EVO781	54 in	Kawasaki EVO781 EFI	

Torque Specifications

SAE Bolt Torque

Torque estimates based on clamp load (75% of proof strength) as specified in SAE J429 and ASME 574.

Diameter and Thread Pitch						
	SAE Grade 5		SAE Grade 8		Socket Head Cap Screw	
	Dry	Lubed	Dry	Lubed	Dry	Lubed
1/4-20	101 in•lb 11.4 N•m	76 in•lb 8.6 N•m	143 in•lb 16.2 N•m	107 in•lb 12.1 N•m	168 in•lb 19 N•m	120 in•lb 13.6 N•m
1/4-28	116 in•lb 13.1 N•m	87 in•lb 9.8 N•m	147 in•lb 16.6 N•m	123 in•lb 13.9 N•m	192 in•lb 21.7 N•m	144 in•lb 16.3 N•m
5/16-18	209 in•lb 23.6 N•m	157 in•lb 17.7 N•m	295 in•lb 33.3 N•m	221 in•lb 25 N•m	348 in•lb 39.3 N•m	264 in•lb 29.8 N•m
5/16-24	231 in•lb 26.1 N•m	174 in•lb 19.7 N•m	327 in•lb 36.9 N•m	245 in•lb 27.7 N•m	384 in•lb 43.4 N•m	288 in•lb 32.5 N•m
3/8-16	372 in•lb 42 N•m	276 in•lb 31.2 N•m	44 ft•lb 59.7 N•m	33 ft•lb 44.7 N•m	51 ft•lb 69.1 N•m	38 ft•lb 51.5 N•m
3/8-24	420 in•lb 47.5 N•m	312 in•lb 35.3 N•m	49 ft•lb 66.4 N•m	37 ft•lb 50.2 N•m	58 ft•lb 78.6 N•m	43 ft•lb 58.3 N•m
7/16-14	49 ft•lb 66.4 N•m	37 ft•lb 50.2 N•m	70 ft•lb 94.9 N•m	52 ft•lb 70.5 N•m	81 ft•lb 109.8 N•m	61 ft•lb 82.7 N•m
7/16-20	55 ft•lb 74.6 N•m	41 ft•lb 55.6 N•m	78 ft•lb 105.8 N•m	58 ft•lb 78.6 N•m	91 ft•lb 123.4 N•m	68 ft•lb 92.2 N•m
1/2-13	75 ft•lb 101.7 N•m	57 ft•lb 77.3 N•m	106 ft•lb 143.7 N•m	80 ft•lb 108.5 N•m	124 ft•lb 168.1 N•m	93 ft•lb 126.1 N•m
1/2-20	85 ft•lb 115.2 N•m	64 ft•lb 86.8 N•m	120 ft•lb 162.7 N•m	90 ft•lb 122 N•m	140 ft•lb 189.8 N•m	105 ft•lb 142.4 N•m
5/8-11	150 ft•lb 203.4 N•m	113 ft•lb 153.2 N•m	212 ft•lb 287.4 N•m	159 ft•lb 215.6 N•m	238 ft•lb 322.7 N•m	179 ft•lb 242.7 N•m
5/8-18	170 ft•lb 230.5 N•m	127 ft•lb 172.2 N•m	240 ft•lb 325.4 N•m	180 ft•lb 224 N•m	270 ft•lb 366.1 N•m	202 ft•lb 273.9 N•m
3/4-10	267 ft•lb 362 N•m	200 ft•lb 271.2 N•m	376 ft•lb 509.8 N•m	282 ft•lb 382.3 N•m	423 ft•lb 573.5 N•m	317 ft•lb 429.8 N•m
3/4-16	297 ft•lb 402.7 N•m	223 ft•lb 302.3 N•m	420 ft•lb 569.4 N•m	315 ft•lb 427.1 N•m	472 ft•lb 640 N•m	354 ft•lb 480 N•m
7/8-9	429 ft•lb 581.6 N•m	322 ft•lb 436.6 N•m	606 ft•lb 821.6 N•m	455 ft•lb 616.9 N•m	682 ft•lb 924.7 N•m	511 ft•lb 692.8 N•m
7/8-14	474 ft•lb 642.7 N•m	355 ft•lb 481.3 N•m	669 ft•lb 907 N•m	502 ft•lb 680.6 N•m	752 ft•lb 1019.6 N•m	564 ft•lb 791.8 N•m

Metric Bolt Torque

Torque estimates based on clamp load (75% of proof strength) as specified in ISO-898-1.

Size and Thread Pitch	 Class 8.8		 Class 10.9		 12.9 Socket Head Cap Screw	
	Dry	Lubed	Dry	Lubed	Dry	Lubed
M5 X 0.80	54 in•lb 6.1 N•m	41 in•lb 4.6 N•m	78 in•lb 8.8 N•m	59 in•lb 6.7 N•m	91 in•lb 10.3 N•m	68 in•lb 7.7 N•m
M6 X 1.00	92 in•lb 10.4 N•m	69 in•lb 7.8 N•m	133 in•lb 15 N•m	99 in•lb 11.2 N•m	156 in•lb 17.6 N•m	116 in•lb 13.1 N•m
M7 X 1.00	156 in•lb 17.6 N•m	116 in•lb 13.1 N•m	222 in•lb 25.1 N•m	167 in•lb 18.9 N•m	260 in•lb 29.4 N•m	195 in•lb 22 N•m
M8 X 1.25	225 in•lb 25.4 N•m	169 in•lb 19.1 N•m	333 in•lb 37.6 N•m	242 in•lb 31.3 N•m	377 in•lb 42.6 N•m	284 in•lb 32.1 N•m
M10 X 1.50	37 ft•lb 50.2 N•m	28 ft•lb 38 N•m	53 ft•lb 71.9 N•m	40 ft•lb 54.2 N•m	62 ft•lb 84.1 N•m	47 ft•lb 63.7 N•m
M12 X 1.75	65 ft•lb 88.1 N•m	49 ft•lb 66.4 N•m	93 ft•lb 126.1 N•m	69 ft•lb 93.6 N•m	108 ft•lb 146.4 N•m	81 ft•lb 109.8 N•m
M14 X 2.00	104 ft•lb 141 N•m	78 ft•lb 105.8 N•m	148 ft•lb 200.7 N•m	111 ft•lb 150.5 N•m	173 ft•lb 234.6 N•m	130 ft•lb 176.3 N•m
M16 X 2.00	161 ft•lb 218.3 N•m	121 ft•lb 164.1 N•m	230 ft•lb 311.8 N•m	172 ft•lb 233.2 N•m	269 ft•lb 364.7 N•m	202 ft•lb 273.9 N•m
M18 X 2.50	222 ft•lb 301 N•m	167 ft•lb 226.4 N•m	318 ft•lb 431.2 N•m	238 ft•lb 322.7 N•m	372 ft•lb 504.4 N•m	279 ft•lb 378.3 N•m
M20 X 2.50	314 ft•lb 425.7 N•m	235 ft•lb 318.6 N•m	449 ft•lb 608.8 N•m	337 ft•lb 456.9 N•m	525 ft•lb 711.8 N•m	394 ft•lb 534.2 N•m
M22 X 2.50	428 ft•lb 580.3 N•m	321 ft•lb 435.2 N•m	613 ft•lb 831.1 N•m	460 ft•lb 623.7 N•m	716 ft•lb 970.8 N•m	537 ft•lb 728.1 N•m
M24 X 3.00	543 ft•lb 736.2 N•m	407 ft•lb 551.8 N•m	776 ft•lb 1052.1 N•m	582 ft•lb 789.1 N•m	908 ft•lb 1231.1 N•m	681 ft•lb 923.3 N•m

SECTION 2

SAFETY

Safety Symbols

Hazard alerts in this manual are used to alert operators, bystanders, and service personnel to hazardous operating and maintenance practices. Each hazard alert contains a hazard-alert symbol and a signal word that identifies the severity of the hazard if the warning is not followed.

The following hazard alerts are used in this manual:

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to personal injury. Notice signs are typically used for activities that result in property damage.

Machine Safety Guidelines

WARNING

Untrained people or failure to follow instructions can result in serious injury or death. Read all instructions before operating.

Never allow untrained people or anyone under the age of 16 to operate this machine. It is the owner's responsibility to get training and see to it that anyone who has permission to use your machine receives the proper training.

WARNING

Flying debris from machine deck can cause serious injury or death to bystanders and can damage property. Never operate with missing or damaged chute.

Do not mow around people. The factory discharge chute is designed to deflect debris downward, but it could be possible for debris to be thrown in a way that can cause damage to people or property. Seek additional training when possible to learn more about safety techniques and practices.

DANGER

Contact with rotating cutting blades case cause serious injury or death. Never put hands, feet, or objects near blades when engine is running.


This machine is capable of amputating hands and feet and throwing objects. Failure to observe safety instructions could result in serious injury or death.

Machine Decals

All safety decals on the machine must remain in place, intact, and visible. Make sure to have a good understanding of the decals prior to operating the machine. Become familiar with all decal locations and their purpose.

Decal, Main Safety


PN: 091-3152-00




- Read operators manual before use the machine.
- Do not operate the machine without being trained.

SAFETY

- Wear proper eye and ear protection when operating the machine.



- Remove objects in mowing area prior to operating the machine.
- Keep safe operating distance from people, animals, objects, and buildings.
- Stop machine when children or others are near.



Thrown Objects Hazard

- Keep discharge chute down and in place while operating to avoid objects being thrown from the machine.
- Do not mow without discharge chute in place.




Amputation Hazard

- Keep hands and feet away from rotating parts.
- Do not operate unless all guards are in place.




Operation Hazard

- Do not carry passengers, especially children. They may fall off or return for another ride when you are not expecting it.
- Look down, behind, and to the side while backing up.




Roll-over Hazard

- Operating on slopes and wet grass can cause instability issues resulting in loss of control and possible rollover.
- Do not operate on slopes over 15 degrees.
- Reduce speed and use extreme caution on slopes.



Transporting Hazard

- Do not operate on any loading surface/ramp exceeding 15 degrees.
- Never use individual ramps to load or unload the machine.
- Raise deck to highest height before loading.




Shut Down Procedures

- Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
- Turn the fuel shutoff valve to the OFF position.

Decal, Cutting Deck Safety

PN: 091-3034-00



Personal Protection Equipment (PPE)

Make sure all personal protective equipment (PPE) is in good working condition before use.

Hearing Protection



Always wear hearing protection, such as earplugs or earmuffs with a noise reduction rating (NRR) of 25 dB or higher, when operating the machine. Prolonged exposure to loud noise can cause permanent hearing impairment or loss of hearing.

Eye Protection



Always wear safety glasses, goggles, or a face shield that meets ANSI Z87.1 standards when operating or servicing the machine. Flying debris, dust, and other hazards can cause serious eye injury or permanent vision loss.

Foot Protection



Always wear sturdy, closed-toe footwear with slip-resistant soles when operating or servicing the machine. Never operate the machine while barefoot or wearing sandals, open-toed shoes, or loose footwear. The rotating blades and other moving components can cause severe foot and ankle

injuries.

Hand Protection



Always wear heavy-duty work gloves when handling blades or performing service and maintenance on the machine. Blade edges are extremely sharp and can cause serious lacerations even when the machine is not running.

Clothing

Wear close-fitting clothing when operating or servicing the machine. Loose clothing, drawstrings, or dangling accessories can become entangled in moving parts. Do not wear jewelry while operating or servicing the machine.

General Operation

⚠ WARNING

Failure to follow these general safety operation practices below can result in serious injury or death.

- Read, understand, and follow all instructions on the machine and in the manual before starting.
- Only allow responsible adults who are familiar with the instructions to operate this machine. Never allow anyone under the age of 16 to operate this machine.
- Do not operate the machine while under the influence of alcohol or drugs.
- Smartphones should not be used while operating the machine.
- Always wear eye protection when operating or servicing the machine.
- Always wear ear protection, such as earplugs, while mowing.
- Clear the area of objects such as rocks, wire, toys, etc., which could be thrown by the blades.
- Keep the entire machine free of grass, leaves, or other debris buildup. Failure to do so can affect the safety and functionality of the machine, as well as increase the danger of a fire due to contact with the hot surfaces of the machine.
- Always operate the machine in daylight or with adequate working lights.
- Never carry passengers.
- Do not put hands or feet near rotating parts or under the machine. Keep clear of the discharge opening at all times.
- Never direct discharged material toward anyone. Avoid discharging material against a wall or obstruction as material may ricochet back toward the operator.

- Stop the blades when crossing gravel surfaces.
- Always maintain a safe distance from people and pets just prior to and during operation. Stop the machine if anyone enters the area.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing up.
- Never operate the machine without the discharge chute, grass catcher, or other safety devices correctly in place and functioning properly.
- Be alert of surroundings. Watch for rocks, stumps, mounds, depressions, and low hanging limbs or objects that could be potentially hazardous while mowing.
- If you strike something with the machine, turn the machine and blades off, engage the parking brake, and inspect the machine for damage. Repair machine before resuming if necessary.
- Slow down before turning.
- Watch for traffic when operating near or crossing roadways.
- Always disengage blades, place steering controls in neutral, engage parking brake, and remove ignition key when leaving operator's seat. Never leave a running machine unattended. Disengage blades when not mowing.
- Shut off engine, allow all moving parts to come to a complete stop, and allow to cool before performing any of the following actions: cleaning or inspecting the machine for damage, removing the grass catcher, or unclogging the discharge guard.
- Prevent fires by keeping deck, engine, and exhaust areas clear of grass clippings and other debris. Do not back or park the machine over, or immediately adjacent to, flammable materials.
- Use extra care when loading or unloading the machine onto a trailer or truck.
- Data indicates that operators 60 years of age and above are involved in a large percentage of riding machine related injuries. These operators should periodically evaluate their ability to operate the riding machine safely enough to protect themselves and others from serious injury.

Safety Interlock System

WARNING

Never attempt to bypass, disable, or modify the safety interlock system or any of its components. An incomplete or modified safety interlock system can result in serious injury or death.

The machine is equipped with a safety interlock system (SIS) that prevents unintended starting and shuts off the engine in certain conditions. If any interlock fails to operate as described, do not operate the machine. Contact your authorized Bad Boy Mowers dealer for service.

Test the safety interlock system before every use. See Safety Interlock System Test in the Pre-Operation chapter.

Fueling

WARNING

Use extreme care in handling fuel. Fuel is extremely flammable and the vapors are explosive. Failure to follow these warnings could cause serious injury or death.

- Ensure to use the proper fuel for your machine. Do not use fuel containing more than 10% ethanol.
- Use extreme care in handling fuel. Fuel is flammable and the vapors are explosive. Failure to follow these warnings could cause serious injury or death.
- Extinguish all cigarettes, cigars, pipes, and all other sources of ignition.
- Never remove fuel cap or add fuel with the engine running.
- Allow engine to cool for a minimum of 5 minutes (longer on exceptionally hot days >95°F) before refueling.
- Never fuel the machine indoors.
- Remove equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel equipment with a portable container, rather than from a fuel dispenser nozzle.
- Use only an approved fuel container.
- Never fill fuel containers inside a machine or on a truck or trailer bed with a plastic liner. Static electricity can ignite fuel vapors. Always place fuel containers on the ground away from your machine before filling.
- Wipe up all fuel spills with a cloth or rag and dispose of properly.
- Securely replace and tighten the cap once the machine has been refueled.
- Store fuel out of reach of children.
- Store fuel in an approved fuel container and in a well-ventilated area.

Slope Operation and Guide

⚠ WARNING

Operating on slopes and wet grass can cause instability issues resulting in loss of control and possible rollover. Failure to follow these warnings could cause serious injury or death.

- Avoid operating your machine on slopes with these thresholds
 - 5 degrees transverse (across the slope)
 - 10 degrees uphill
 - 15 degrees downhill




Figure 1 Guide to Determine Slope

To verify the slope, line the 0 degree mark in Figure 1 with a horizontal surface. Sight across the slope. If the slope is beyond the 15 degree line, the slope is too steep to operate safely. Slope can also be calculated using a smartphone built in level or inclinometer tool. This must be done with the machine powered off.

- Watch for holes, ruts, bumps, rocks, or other hidden objects that tall grass can obscure. Uneven terrain could overturn the machine.
- Choose a low ground speed when operating the machine on a slope.
- Do not mow on wet grass, the tires may lose traction.
- Do not attempt to coast down a slope in the neutral position.
- Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the blades and proceed slowly straight down the slope.
- Avoid sudden blade engagement, which can shift weight and affect stability.

- Keep all movement on slopes slow and gradual. Sudden changes in speed or direction could cause the machine to roll over.
- Do not try to stabilize the machine by putting your foot on the ground.
- Do not mow near drop-offs, ditches, or embankments, especially after rain as the drop-off edges can become extremely weak. The machine could suddenly and dangerously rollover if a tire goes over the edge of a drop-off.
- Be aware of what is located at the bottom of slopes. For example: rocks, water, cliffs, and roadways.

Children

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. **NEVER** assume that children will remain where you last saw them.

⚠ WARNING

Never allow children to ride on or operate the machine. Be sure the area is clear of bystanders, pets, and especially children. Failure to follow these warnings could cause serious injury or death.

- Keep children out of the mowing area and in the watchful care of a responsible adult other than the operator.
- Maintain alertness and turn machine off if a child enters the area.
- Before and while backing up, look behind and down for small children.
- Use extreme care when approaching blind corners, shrubs, trees, or other objects that may block your view of a child.
- Never carry children, even with blades shut off. They may fall off and be seriously injured or interfere with safe machine operation.
- Never allow children to operate the machine. The minimum age to operate this machine is 16 years old. It is the owner's responsibility to ensure that anyone who has permission to use this machine meets this requirement and has received proper training.
- Never leave the key in the ignition, especially around children.

Service

⚠ WARNING

Do not run the engine indoors or in an enclosed space where carbon monoxide fumes can collect. Failure to

follow these warnings could cause serious injury or death.

- Park the machine on level ground.
- Never allow untrained personnel to service the machine.
- Understand service procedures before doing work.
- Keep all nuts and bolts tight to be sure the equipment is in safe working condition. Never operate a poorly maintained machine.
- Always have the fuel shutoff valve in the OFF position when servicing the machine.
- Check the discharge guard frequently. Replace with manufacturer's recommended parts when necessary.
- Never interfere with the intended function of a safety device or reduce the protection provided by a safety device. Check their proper operation regularly.
- Do not touch hot areas of the machine.
- Never make any adjustments or repairs with the engine running.
- Machine blades are sharp. Wrap the blade or wear gloves before servicing them.
- Never apply heat to straighten or weld a damaged or cracked blade.
- Check parking brake operation frequently. Adjust and service the brake as required.
- Do not attempt to mount a tire without the proper equipment and experience to perform the job.
- Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure.
- The loss of hydrostatic drive line power may result in the loss of hydrostatic braking capability.
- Some cleaning solvents are flammable. Use only approved cleaning materials: Do not use explosive or flammable liquids to clean the equipment.
- To avoid possible fire, do not use cleaning solvents in an area where a source of ignition may be present.
- Clean up oil or fuel spillage and remove any fuel-soaked debris.

Environmental

- If not disposed of correctly, oils can contaminate and pollute soil, groundwater, streams, and rivers. Used oil and filters can be recycled to aid in the conservation of natural resources and help the environment.
- Adhere to all regulations when disposing of oil, fuel, filters, batteries, used parts, and other potentially harmful items.
- Discard used cleaning material in the appropriate containers according to local, state, and federal regulations.

Battery

WARNING

Failure to follow these safety precautions can cause serious injury or death.

- Inspect the battery case regularly for damage, cracks, or swelling. Do not use or charge a battery that shows signs of damage or swelling. Contact your authorized Bad Boy dealer for inspection or replacement.
- Charge only with a lithium-approved battery charger. Never use the machine's charging system to charge a discharged battery.
- Keep the battery away from open flames, sparks, and other ignition sources at all times. Never charge the battery in an enclosed, unventilated space.
- Never lean over the battery while charging, testing, or jump-starting.
- Do not expose the battery to temperatures outside the manufacturer's specified charging and operating range.
- Inspect battery cable connections regularly. Connections should be tight and free of damage.

.

Transporting

WARNING

Loading or unloading a machine greatly increases the chance of the machine losing control and tipping over. Failure to follow these warnings could cause serious injury or death.

- Never engage the blades while loading or unloading the machine.
- Never use individual ramps to load or unload the machine. Always use a full-width ramp or trailer gate.
- Never tow the machine onto a trailer. Always use a winch to load the machine for transporting.
- Do not operate on any loading surface/ramp exceeding 15 degrees.
- Never accelerate or decelerate suddenly while loading or unloading the machine on a trailer.
- Always ensure the mode of transportation is suitable to bear the weight of the machine.
- Always use straps rated at a minimum of 1.5 times the weight of the machine when securing the machine for transport.

⚠ CAUTION


Improper preparation before loading can result in loss of machine control or damage. Failure to follow these cautions could cause injury or equipment damage.

- Always set the deck to maximum height before loading or unloading the machine.
- Always engage the parking brake before loading or unloading the machine.
- Always rotate the fuel shutoff valve to the OFF position when transporting the machine.
- In wet conditions, tires may spin during loading or unloading. Wait for dry conditions before loading or unloading if necessary.
- Always allow the engine and exhaust to cool completely before parking the machine inside an enclosed space.

SECTION 3


CONTROLS

Machine Overview



- | | | | |
|---|---------------------------------|---|--------------------------------|
| A | Oil Light | K | MIL Light |
| B | PTO | L | Tachometer |
| C | Ignition | M | Rest Bar |
| D | Parking Brake | N | Knee Pad Adjustment Knob, Left |
| E | Rest Arm Adjustment | O | Fuel Tank, Left |
| F | Control Arm, Right | P | Control Arm, Left |
| G | Fuel Tank, Right | Q | Rest Bar |
| H | Fuel Gauge | R | Deck Height |
| I | Knee Pad Adjustment Knob, Right | S | Deck Height Lever |
| J | USB Port | | |

Control Panel



Throttle

- A Controls engine speed. Move the lever towards the front of the machine to increase engine rpm, towards the rear of the machine to decrease engine rpm.

Oil Light

- B Indicator light when oil is low and requires immediate attention.

PTO

- C Provides power to the blades. Pull up on the knob to engage the blades. Push the knob down to disengage the blades.

Ignition

- D Four positions include OFF, LIGHTS, RUN and START.

Parking Brake

- E Engages the parking brake. Pull the lever up to engage. Push the lever down to disengage.

Control Arm, Left

- F Controls forward and reverse movement of the left side of the machine. Neutral is the resting position.

Hours/Tachometer

- G A dual-function display that shows current engine RPM during operation and tracks cumulative engine run time, in increments up to 9,999.9 total hours.

MIL Light

- H Malfunction indicator light indicates when there is a malfunction in the electronic fuel injection system and requires immediate attention. Available on EFI models only.

USB Port

- I Allows for digital devices to be charged while in operation.

Control Arm, Right

- J Controls forward and reverse movement of the right side of the machine. Neutral is the resting position.

SECTION 4

PRE-OPERATION

Fuel

Use fresh, clean fuel with an octane rating of 87 or higher. Only fuels with an ethanol content of 10% or less are approved for use. Use of fuel with an ethanol content greater than 10%, including E-15, can result in premature engine failure and will void the warranty.

Fuel Shutoff

The fuel shutoff valve controls fuel flow from the tank to the engine. Closing the valve when the engine is not in use prevents fuel from reaching the engine, reducing the risk of fire or fuel leak. Always close the fuel shutoff valve after each use and before performing service, storage, or transport.

⚠ CAUTION

Failure to close the fuel shutoff valve when the engine is not in use can result in fuel leaks and fire hazard.

1. Locate the fuel shutoff valve.




Figure 1: Fuel Shutoff Valve

2. Rotate the valve clockwise to the open (ON) position or counterclockwise to the closed (OFF) position.

Fueling

⚠ CAUTION

Improper fuel handling can cause an explosion or fire. Failure to follow these warnings could cause serious injury or death.

- Always handle fuel with care.
- Stop the engine and allow to cool before fueling.
- Add fuel outdoors or in a well-ventilated area.

- Do not allow smoking, open flames, or sparks near the area when fueling.
 - Do not overfill the fuel tank.
 - Use a funnel if necessary to avoid spills.
 - If fuel is spilled on clothing or skin, wash off immediately with soap and water.
 - Do not start engine if fuel is spilled.
1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
 2. Turn the fuel shutoff valve to the OFF position.
 3. Allow the engine to cool before adding fuel.
 4. Remove the fuel cap by rotating it counterclockwise.




Figure 2: Fuel Cap

5. Begin filling.
6. Stop fueling when the fuel level reaches the bottom of the filler neck.
7. Install the fuel cap and rotate it clockwise until tight.
8. Repeat for the second tank.

Control Arm Stop

The control arm stop limits the forward travel of the control arms, which affects both maximum speed and operator standing position. Three adjustment positions are available to accommodate different operator preferences.

1. Locate the control arm stop plunger (1) on the right side of the podium.




Figure 3: Control Arm Plunger

PRE-OPERATION

2. Pull the plunger outward and hold it to disengage it from the current hole position.
3. Reposition the control arm stop to hole position 1, 2, or 3 to achieve the desired standing position.
4. Release the plunger and confirm it is fully seated in the selected hole.

Platform Pad

The platform pad can be repositioned up or down to accommodate different operator heights and standing preferences.

1. Loosen the retainers on both sides by a 1/2 turn.
2. Pivot the pad and pad plate up to expose the four 5/16-18 x 1 in. bolts.
3. Loosen the bolts securing the platform pad to the pad plate.
4. Reposition the platform pad up or down to the desired height.
5. Tighten each bolt to 209 in-lbs to secure the platform pad in the new position.
6. Pivot the pad and pad plate back down into the operating position.

Deck Height

The cutting deck can be adjusted from 2 to 5 in. in 1/4 in. increments to achieve the desired cutting height before operating. Always adjust deck height while the mower is off and the blades are disengaged.

⚠ CAUTION

Always disengage the blades and turn the mower off before adjusting the deck height. Never adjust the cutting height while the blades are engaged.




Figure 4: Deck Height Adjustment

1. Disengage the blades and turn the mower off.
2. Locate the deck lift lever (1) to the left side of the podium.
3. Pull the lever towards the rear of the machine until the deck lever lock (2) locks into place.
4. Remove the pin (3) from the deck height adjustment and insert it into the hole of the desired cutting height. Quickly pull back on the deck lift lever (1) to disengage the deck lever lock (2) to allow the deck to return to the new height.

Safety Interlock System

⚠ WARNING

Do not tamper with or bypass the safety interlocks. Failure to follow this warning could cause serious injury or death.

The machine is equipped with a safety interlock system (SIS) that must be tested before every use. The SIS prevents the engine from starting unless specific operating conditions are met. After the machine starts successfully, a separate test verifies that the engine shuts off when the operator leaves the operating position after the PTO is ON. If any one of the safety interlocks do not function as described, do not operate the machine. Contact your authorized Bad Boy Mowers dealer for service.

Parking Brake — The machine will not start unless the parking brake is engaged.

Control Arms — The machine will not start unless the control arms are in the neutral position. Neutral position is the place the control arms return to.

PTO Switch — The machine will not start unless the PTO switch is in the OFF position.

Operator Presence — The engine will shut off if the operator leaves the operating position after the PTO is ON.

Test 1

Parking Brake	 Disengaged	FAIL
Control Arms	Neutral	
PTO	 OFF	

Test 2

Parking Brake	 Engaged	FAIL
Control Arms	Forward or Reverse	
PTO	 OFF	

Test 3

Parking Brake	 Engaged	FAIL
Control Arms	Neutral	
PTO	 ON	

Operator Presence Test

1. Stand in the operator position on the mower.
2. Start the engine using the starting conditions.


Parking Brake
On

Neutral
Control Arms


PTO Off

3. Engage the PTO to ON.
4. Slowly step off from the operating position. The engine should stop.

If the engine does not stop, do not operate the machine. Contact your authorized Bad Boy Mowers dealer for service.

SECTION 5

OPERATION

⚠ WARNING

Failure to follow the operating instructions in this manual and the safety instructions in the Safety chapter can result in serious injury or death. Read General Operation Safety in the Safety chapter before operating the machine.

Starting the Machine

Take time to become familiar with the location and function of all controls before operating. Start at reduced speed until comfortable with how the machine responds.

1. Confirm the area around and beneath the machine is free of bystanders, pets, and obstructions.
2. Turn the fuel shutoff valve clockwise to ON.
3. Set the parking brake.
4. Confirm the PTO switch is in the OFF position.




Figure 1: PTO OFF

5. Move the control arms to the neutral position to release the neutral lock.
6. If the engine has not run recently, pull the choke knob to engage the choke.
7. Set the throttle between the half and full throttle positions.




Figure 2: Throttle Half Way

8. Turn the key to the start position and hold until the engine starts, then release.




Figure 3: Turn the Key to Start

9. Once the engine is running, push the choke knob in to disengage the choke.
10. Increase the throttle to the fast position.




Figure 4: Throttle in Fast Position

11. Engage the PTO switch.




Figure 5: PTO ON

Control Lever Arms

The control lever arms move your machine in the forward, backward, left turn, and right turn position.

Forward

With the control arms together, push them forward to move the machine forward.

Backward

With the control arms together, pull them back towards the seat to move the machine backward.

Left

While leaving the left control arm in position, push the right control arm forward to turn the machine left.

Right

While leaving the right control arm in position, push the left control arm forward to turn the machine right.

Neutral

Release the control arms to return to neutral.

PTO Switch

⚠ WARNING

Never put hands, feet, or objects into or under machine when engine is running. Failure to follow these warnings could cause serious injury or death.

1. Verify the discharge chute is down and the area is clear of bystanders.
2. Follow steps to start machine.
3. Increase RPM by moving the throttle control lever to the fast throttle position. The throttle must be in fast mode for the PTO to be engaged.




Figure 6: Throttle in Fast Position

4. Pull up on the PTO switch to engage the blades.




Figure 7: PTO ON

5. To disengage the blades, push down on the PTO switch.




Figure 8: PTO OFF

Troubleshooting

Starting / No-Start

Problem	Cause	Solution
Machine will not start	Battery discharged or corroded terminals	Charge battery. Clean and tighten terminal connections. Replace battery if it will not hold a charge.
	Fuel tank empty or fuel older than 30 days	Fill tank with fresh fuel. Do not use fuel containing more than 10% ethanol. Drain and replace fuel that is older than 30 days or shows signs of contamination or water.
	Spark plug fouled, damaged, or wire disconnected	Inspect spark plug condition. Replace if fouled or electrode is worn. Ensure spark plug wire is firmly seated on the plug terminal.
	Air filter dirty or clogged	Inspect air filter element. Clean or replace as needed. A restricted air filter reduces airflow and prevents starting. See the Maintenance chapter for air filter service intervals.
	Main fuse blown	Check the 25-amp main fuse. Replace with a fuse of the same amperage only. Do not substitute a higher-rated fuse. Locate and correct the underlying cause before returning the machine to service.
	Damaged wiring or bare/loose connections	Visually inspect all visible wiring and connectors for damage, corrosion, or loose connections. Do not operate the machine with damaged wiring. Contact your authorized Bad Boy dealer for electrical diagnosis.
	Fuel shutoff valve in OFF position	Turn the fuel shutoff valve to the ON position before starting.

Engine Issues

Problem	Cause	Solution
Engine runs rough or surges	Stale or contaminated fuel	Drain fuel system and refill with fresh fuel. Do not use fuel older than 30 days or fuel containing more than 10% ethanol.
	Dirty or clogged air filter	Inspect and clean or replace the air filter element. See the Maintenance chapter for air filter service intervals.
	Spark plug fouled or worn	Inspect and replace spark plug as needed.
	EFI Malfunction Indicator Light (MIL) illuminated	Do not continue operating. The MIL indicates a fault in the electronic fuel injection system. Contact your authorized Bad Boy dealer for diagnosis.
Engine overheats or shuts off under load	Cooling fins or air intake screen obstructed	Stop the engine and allow to cool. Inspect and clean all cooling fins and air intake screens. Remove accumulated grass, debris, or dirt.
	Engine oil level low	Check oil level on a level surface with the engine off. Add oil as needed. Do not overfill.
	Operating in conditions that exceed the machine's rated capacity	Reduce ground speed or mowing width to reduce engine load. Ensure the engine is operating at full throttle during mowing.
Engine shuts off unexpectedly during operation	Operator presence switch activated	The machine is equipped with an operator presence system. Remain on the platform during operation.
	Fuel tank empty	Refuel the machine. Check fuel level before each use.
	Low oil pressure shutdown	Allow engine to cool. Check oil level and add oil as needed. Do not restart until oil level is correct. If the engine shuts down repeatedly for low oil pressure, contact your authorized Bad Boy dealer.

Cutting Quality

Problem	Cause	Solution
Uneven cutting pattern or poor quality of cut	Tire pressure uneven or incorrect	Check and adjust tire pressure in all tires to the specified pressure. Uneven tire pressure causes the deck to ride unevenly. See the Specifications section for correct tire pressure.
	Blades dull or damaged	Inspect blades for wear, nicks, or damage. Sharpen or replace blades. Blades should be inspected and sharpened at least once per season or more frequently in abrasive conditions.
	Blades not tightened to specification	Inspect blade hardware and torque blade bolts to specification.
	Deck belt worn, loose, or damaged	Inspect the deck drive belt for wear, cracking, or glazing. Replace if damaged.
	Deck belt tension incorrect	Check and adjust deck belt tension.
	Deck not level	Check and adjust deck level.
	Grass and debris buildup on the underside of the deck	Engage the parking brake, shut off the engine, remove the ignition key, and turn the fuel shut-off valve to the OFF position. Clean the underside of the deck thoroughly. Regular cleaning prevents buildup that interferes with blade performance and airflow.
	Engine not at full throttle during mowing	Always operate at full throttle when mowing. Reduced throttle results in lower blade tip speed and poor cut quality.
	Ground speed too fast for conditions	Reduce ground speed, especially in tall, thick, or wet grass. Allow the blades to fully process material before advancing.
Scalping; deck cutting into ground	Cutting height set too low for terrain	Raise the cutting height. On uneven terrain, raise the cutting height to prevent the deck from contacting high spots.
	Deck not level — one side lower than the other	Level the cutting deck.

Problem	Cause	Solution
Material discharging unevenly or clumping in path	Grass wet or too tall and dense	Allow grass to dry before mowing. Raise the cutting height for the first pass, then lower to the desired height and make a second pass perpendicular to the first.
	Ground speed too fast for material density	Reduce ground speed to allow blades to fully process material before it exits the discharge chute.
	Discharge chute blocked or damaged	Stop the machine. Engage the parking brake, shut off the engine, remove the ignition key, and turn the fuel shutoff valve to the OFF position. Clear any blockage from the discharge chute. Inspect the chute for damage and replace if needed.

Blades Will Not Engage

Problem	Cause	Solution
Blades will not engage when blade switch is activated	Operator presence switch not engaged	Ensure operator is properly positioned on the platform. The blade engagement circuit is disabled when the operator presence switch is not activated.
	Operator presence switch connector loose or disconnected	Check the connector at the platform switch. Ensure the connector is fully seated.
	Blade switch connector loose or disconnected	Check the connector on the underside of the blade engagement switch. Ensure the plug is fully seated and locked.
	PTO fuse blown	Check the 10-amp PTO fuse located under the operator console. Replace with a fuse of the same amperage only. Do not substitute a higher-rated fuse. Identify and correct the cause of the overload before returning to service.
	Deck belt broken or off pulleys	Stop the machine. Engage the parking brake, shut off the engine, remove the ignition key, and turn the fuel shutoff valve to the OFF position. Inspect the deck belt. Replace if broken.

Drive and Steering Issues

Problem	Cause	Solution
Machine pulls or drifts to one side	Drive tracking out of adjustment	Perform a tracking adjustment. See the Service section.
	Tire pressure uneven between left and right sides	Check and equalize tire pressure on both drive tires.
Machine will not move in forward or reverse	Parking brake engaged	Disengage the parking brake before attempting to drive.
	Neutral bypass engaged for towing	Disengage the neutral bypass valve(s) before operating under power.
	Hydrostatic drive system low on fluid	Check hydraulic fluid level. Add fluid as needed using only the fluid type specified in the Service section.
	Drive belt broken or off pulleys	Inspect the drive belt for breakage or displacement. Replace or reinstall as needed.
Control levers not returning to neutral properly	Control lever linkage out of adjustment	Inspect control arm linkage for proper adjustment.

Electrical Issues

Problem	Cause	Solution
Battery drains quickly or will not hold a charge	Battery at end of service life	Test battery under load. Replace battery if it will not hold a charge. See Battery Safety for battery handling precautions.
	Battery terminals corroded	Clean battery terminals and cable ends. Apply terminal protector spray after cleaning.
	Machine stored for extended period without battery maintenance	Charge battery fully before returning to service. For storage periods exceeding 30 days, disconnect the negative battery cable.
No electrical power; dash/display does not illuminate	Main fuse blown	Check the 25-amp main fuse. Replace with a fuse of the same amperage only. If the fuse blows again immediately, contact your authorized Bad Boy dealer for electrical diagnosis.
	Battery cable loose or disconnected	Inspect battery cable connections. Ensure both positive and negative cables are tight and corrosion-free.
EFI Malfunction Indicator Light (MIL) illuminated	Fault detected in the electronic fuel injection system	Do not continue operating. Contact your authorized Bad Boy dealer for diagnosis. Do not attempt to clear or ignore fault codes; operating with an active fault code may result in engine damage.
Hour meter or display not functioning	Loose connector or blown fuse	Check fuse for display circuit. Inspect display connector for secure seating.]

Excessive Vibration or Unusual Noise

Problem	Cause	Solution
Excessive vibration during operation	Blade bent, cracked, or missing	Stop the machine immediately. Engage the parking brake, shut off the engine, remove the ignition key, and turn the fuel shutoff valve to the OFF position. Never operate with a damaged or missing blade.
	Blade hardware loose	Stop the machine immediately. Inspect and torque all blade bolts to specification.
	Blade spindle bearing worn or damaged	Stop the machine. Contact your authorized Bad Boy dealer for spindle bearing inspection and replacement.
	Foreign object lodged in cutting deck	Stop the machine immediately. Engage the parking brake, shut off the engine, remove the ignition key, and turn the fuel shutoff valve to the OFF position. Wait for all moving parts to stop completely before inspecting. Remove the object carefully.
	Deck belt worn or damaged	Inspect the deck belt for wear, cracking, fraying, or glazing. Replace if needed.
Unusual noise during operation	Foreign object struck or lodged in cutting deck	Stop the machine immediately. Engage the parking brake, shut off the engine, remove the ignition key, and turn the fuel shutoff valve to the OFF position. Wait for all moving parts to stop completely before inspecting the deck area.
	Blade bolt loose	Stop the machine. Inspect and torque blade hardware to specification.
	Hydrostatic drive making grinding or whining noise	Check hydraulic fluid level. If the noise persists after confirming fluid level is correct, contact your authorized Bad Boy dealer.
	Engine making unusual noise	Stop the machine and allow to cool. Check oil level. Do not restart if oil level is correct and the noise persists. Contact your authorized Bad Boy dealer for engine diagnosis.

Choosing the Right Blade

WARNING

The use of blades that are not Bad Boy blades can result in blade failure. Blade failure during operation can cause serious injury or death.

NOTICE

The use of unapproved blades may void any or all warranty for both machine and engine.

There are two basic styles of mowing blade used on Bad Boy mowers.

Standard blades cut and discharge clippings out from the deck, onto the lawn or into a collection system. Also called "2-in-1" (discharging and bagging) or "high-lift" blades, for the higher airflow they create.

Mulching blades have a more curved surface with extra cutting edges to break clippings down further before they settle into the lawn. Also called "3-in-1" (mulching, discharging, and bagging) or "all-purpose" blades. Because mulching blades recirculate airflow, they discharge clippings less efficiently than a standard blade. If cutting or discharge performance suffers with a mulching blade, switch to a standard blade. To mulch with a standard blade, use a mulching kit (mulching blades plus a plug that closes the discharge opening).

The blade installed at the factory is selected for the expected use of each model. To identify which blade is on your machine, compare the part number stamped on the blade to your Operator's Manual or Parts List.

Bad Boy does not recommend aftermarket blades. Contact the blade manufacturer directly for questions about special application or aftermarket blades.

Storage

WARNING

Gasoline is extremely flammable and can be explosive under certain conditions. Drain fuel before storing the machine for extended periods. Drain fuel in a well-ventilated area away from any source of flame or sparks, including appliances with a pilot light. Store fuel in an approved container in a safe location. Failure

to follow this warning could result in serious injury or death.

WARNING

Gasoline is a toxic substance. Dispose of gasoline properly. Contact your local authorities for approved disposal methods.

NOTICE

Change the engine oil before returning the machine to service after a period of storage. For more information, see **"Changing Engine Oil and Oil Filter."**

The machine should be stored in a dry, protected location to prevent weather related damage. Perform the following before storing the machine for 30 days or longer:

1. Add fuel stabilizer to the fuel tanks and run the engine for 5 minutes.
2. Drain the fuel tank completely. Refer to the engine manufacturer's manual for the location and procedure for draining fuel from the carburetor.
3. After draining the fuel tanks, run the engine at low idle until it stalls.
4. Clean the entire machine, including the deck and engine compartment.
5. Remove the spark plugs and pour approximately 1–2 mL (1/2 teaspoon) of engine oil into each spark plug hole. Turn the engine over a few times, then slowly turn it until you feel compression and leave it in that position. This seals air inside the cylinder and helps prevent internal rust.
6. Install the spark plugs.
7. Wipe down the machine with an oily cloth to prevent rust.
8. Remove the battery. Store in a cool, dry place above freezing temperatures.

SECTION 6

MAINTENANCE

Maintenance Schedule

WARNING

Machine maintenance must be done at regular intervals. Failure to do so will result in excessively worn parts and early failures. Use the maintenance intervals as a guide for correct maintenance of the machine.

NOTICE

Maintenance should be performed when the machine is on a flat, firm, and level surface with the parking brake engaged, engine shut off, ignition key removed, and the fuel shutoff valve OFF.

Refer to the legend below to locate detailed instructions for each maintenance item.

X = No dedicated instructions,
self-explanatory check

M = Maintenance chapter

S = Service chapter

O = Engine manual

Maintenance	Every Use	First 8 Hours	Monthly
Check and add engine oil	M		
Check the engine for oil leaks	X		
Check all belts for proper alignment	X		
Check wheel condition and lug nuts	M		
Check for fuel leaks	X		
Check air element(s)	O		
Check for worn or missing safety decals	M		
Check all guards, shields, chutes, and hardware	X		
Check control lever arms	X		
Check for debris on the cutting deck and engine compartment	X		
Check condition of blades	M		
Check battery terminal connections	M		

MAINTENANCE

Maintenance	Every Use	First 8 Hours	Monthly
Check Safety Interlock System	M		
Check that grease points have been recently greased	M		
Check transaxle for leaks	X		
Check operator presence controls	M		
Check for loose nuts and bolts	X		
Check muffler and exhaust system	X		
Clean the machine	X		
Initial oil change		O	
Verify the machine travels straight on a flat, level surface			S
Inspect the machine drive belt, idler pulley(s), and idler spring(s)			X
Inspect the machine control linkage to the directional control arm on the transaxle			X
Ensure that the control arm is securely fastened to the trunnion arm of the transaxle.			X
Inspect the bypass mechanism on the transaxle and the machine linkage to ensure that both actuate and release fully			X
Check the hydrostatic system oil level			X
Check transaxle for leaks			X

Lubrication



Never service or maintain machine with engine running. Failure to follow safety precautions can cause serious injury or death.

The machine has the following grease locations

	Per	Total
Deck Lift Lever (1)	1	1

Control Actuator Arm, Left and Right (2)	1	2
Turnbuckles, Left and Right (3)	2	4




Figure 1: Deck Lift Lever and Control Actuator Arms




Figure 2: Turnbuckle, Front Left




Figure 3: Turnbuckle, Right Rear

Note: NGLI grade #2 multi-purpose gun grease is recommended.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Clean the grease fittings with a cloth. Scrape any dirt/debris off the front face of the fittings.
4. Connect a grease gun to each fitting.

5. Pump grease into the fitting until grease seepage is observed. Be mindful of over-pressurization. Do not force the grease into the component if excessive back pressure is felt as this can lead to reduced life of the component(s).
6. Wipe up any excess grease and dispose of properly.

Debris Removal

It is recommended that you use an air hose or blower to remove dust and debris from the machine, to ensure there is not a buildup of grass on the mower deck and engine compartment, which could become a fire hazard. If you must wash the machine, ensure that you run the engine to operating temp to dry water and engage the blades to spin off any standing water on the pulleys. Avoid spraying water onto electrical components and bearings to prevent premature failure of these parts.

Hydrostatic System

⚠ WARNING

Never service or maintain machine with engine running. Failure to follow this warning could cause serious injury or death.

⚠ WARNING

Moving belts and parts can cause serious injury. Never inspect or service machine while engine is running or with protective guards removed. Failure to follow this warning could cause serious injury or death.

Regular maintenance of the hydrostatic system should include:

- Ensure the current application does not exceed the machine load rating.
- Check oil level. More information can be found in Service - Hydrostatic System.
- Inspect the machine drive belt, idler pulley(s), and idler spring(s). Ensure that no belt slippage can occur. Slippage can cause low input speed to the hydraulic motor.
- Inspect the machine control linkage to the directional control arm on the machine's pump assembly.
- Inspect the hydraulic motor and pump for debris. Keeping the area debris free is important in the overall performance.
- Inspect all external plumbing for possible leaks or loose fittings. An air leak may be difficult to detect on the "suction side" or inlet line to the pump.

Engine Oil

Check the engine oil with every use before starting the engine. Otherwise shortage of the engine oil may cause serious damage to the engine such as seizure.

Bad Boy recommends using a 10W-30 Bad Boy synthetic blend.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Clean the area around the oil gauge before removing it.
4. Remove the oil gauge and wipe it with a clean cloth.
5. Pour the oil slowly to "FULL" mark on the oil gauge.
6. Insert the oil gauge into the tube WITHOUT SCREWING IT IN.
7. Remove the oil gauge to check the oil level. The level should be between "ADD" and "FULL" marks. Do not overfill.
8. Install and tighten the oil gauge.

- A dull blade tears grass instead of cutting it, leaving a frayed, browning edge within hours and increasing load on the engine.
- If the machine strikes a rock, branch, or other object, stop and check the blades for damage before resuming operation.
- Replace a worn, cracked, or damaged blade immediately. Continued use creates a safety hazard and can damage other machine components.

NOTE: Bad Boy recommends blade sharpening and service be performed by a qualified professional.

Battery

WARNING

Failure to follow this warning could result in serious injury or death.

- Inspect the battery case for damage, cracks, or swelling. Do not use a battery that shows signs of damage or swelling. Contact your authorized Bad Boy dealer for replacement.
- Inspect battery cable connections. Connections should be tight and free of damage.
- Charge only with a lithium-approved battery charger. Never use the machine's charging system to charge a discharged battery.

Blades

CAUTION

Mower blades are sharp and can cause injury. Wear thick gloves when handling blades. Keep hands and feet clear of rotating blades. Use approved lifting equipment when working beneath the machine.

Inspect the blades before each use.

Service Schedule

WARNING

Machine service must be done at regular intervals. Failure to do so will result in excessively worn parts and early failures. Use the service intervals as a guide for correct service of the machine.

Refer to the legend below to locate detailed instructions for each service item.

S = Service chapter O = Engine manual

Service	First 8 Hours	Every 50 Hours or Annually	Every 100 Hours or Annually	Every 400 Hours
Initial oil change	S			
Torque wheel lugs		S		
Change engine oil			S/O	
Replace engine oil filter			S/O	
Initial hydraulic oil and filter change			S	
Grease machine			S	
Replace air element and pre-cleaner			S/O	
Replace fuel filter			S/O	
Clean or replace spark plug(s) and set gap			S/O	
Change hydraulic oil and replace filter				S

Commonly Used Parts

This section lists part numbers for items most frequently replaced during routine maintenance, grouped by cutting width or engine as applicable.

Blades

Deck Size	Hi-Lift Fusion	Gator Blade	Wave Blade
36 in	038-3010-00	038-5203-00	038-5215-00
48 in	038-5350-00	038-5000-00	038-4825-00
54 in	038-0001-00	038-0003-00	038-5220-00
61 in	038-6080-00	038-6081-00	038-6090-00

Belts and Filters

Item	Part Number
Hydraulic Filter	063-1050-00
54 in Deck Belt	041-0264-00
61 in Deck Belt	041-0265-00
72 in Deck Belt	041-0266-00
Pump Belt	041-0100-00

Engine Filters and Spark Plug

Item	Briggs	Kawasaki
Fuel Filter	063-6000-00	063-6000-00
Oil Filter	063-8018-00	063-8017-00
Air Filter	063-8019-00 (Pre-cleaner) 063-8020-00	063-8019-00 (Pre-cleaner) 063-8020-00
Spark Plug	015-8000-00	015-8001-00

Oils

Oil	Type	Part Number
Engine	10W-30 (Bad Boy Synthetic Blend Recommended)	085-1030-00
Transaxle	20W-50 Hydrostatic Oil (Bad Boy Hydrostatic Oil Recommended)	085-6000-00

Hydrostatic System

Some of the service procedures presented on the following pages can be performed while the transaxle is mounted on the machine. Any repair procedures as mentioned in the repair section of this manual must be performed after the unit has been removed from the machine.

Cleanliness is a primary means of assuring satisfactory life on repaired units. Thoroughly clean all exposed surfaces prior to any type of maintenance. Cleaning of all parts by using a solvent wash and air drying is usually adequate. As with any precision equipment, all parts must be kept free of foreign material and chemicals.

Protect all exposed sealing surfaces and open cavities from damage and foreign material. The external surfaces should be cleaned before beginning any repairs. Do not use a pressure washer to clean the hydrostatic system.




Figure 1: Top View




Figure 2: Side View




Figure 3: Back View




Figure 4: Bottom View

Fluid Volume and Level

Item	Specification
Fluid Type	SAE 20W-50 Bad Boy Hydrostatic Oil
Case Top-Off Volume	34 fl. oz./1000 mL
Total System Volume	
Fill Port Location	Top of transaxle housing
Drain Port Location	Bottom of transaxle housing

Certain situations may require additional fluid to be added or the fluid fully replaced. In addition to filling the hydraulic system with fluid, an additional 34 fl. oz. (1000 mL) must be added to the case via the fill port at the top of the transaxle. After maintenance or an oil change, follow the Purge Procedure and check the fluid level once the unit has been purged and operated for 1 minute.

Fluid Change Procedure

NOTICE

All fluids should be handled and disposed of according to local, state, and federal regulations.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Place an oil drain pan beneath the drain port at the bottom of the transaxle.
4. Remove the drain port plug and allow the fluid to fully drain.
5. Drain old fluid of all free-flowing oil prior to disposal. Place used oil in appropriate containers and deliver to an approved recycling collection facility.
6. Reinstall the drain port plug.
7. Follow the Adding Fluid procedure above to refill the system and transaxle case.
8. Proceed to the Purge Procedure.

Purge Procedure

⚠ WARNING

Certain procedures require the engine to be operated and the machine to be raised off of the ground. To prevent possible injury to the servicing technician and/or bystanders, ensure the machine is properly secured.

Air trapped in the hydraulic system may cause noisy operation, lack of power or drive after short-term operation, and high operating temperature with excessive expansion of oil. These purge procedures must be performed anytime the hydrostatic system has been opened for maintenance or repair, or if any additional fluid has been added to the system.

Before starting, make sure the reservoir is at the proper fluid level. If it is not, fill per the Adding Fluid procedure above.

The following procedure should be performed with the machine's drive wheels off the ground, then repeated under normal operating conditions.

1. Lift and support the machine so the drive wheels are off the ground.
2. Disengage the parking brake.
3. With the bypass valve open and the engine running, slowly move the directional control in both forward and

reverse directions (10 to 20 times). As air is purged from the unit, the fluid level in the reservoir may drop.

4. With the bypass valve closed and the engine running, slowly move the directional control in both forward and reverse directions (10 to 20 times). Check the fluid level, and add fluid as required after stopping the engine.
5. Repeat steps 3 and 4 until all air is completely purged from the system. When the hydraulic system moves forward and reverse at normal speed and the reservoir fluid remains at a constant level, purging is complete.

Transaxle Bypass

The drive pumps are equipped with transaxle bypass valves. These transaxle bypass valves are located at the rear of the pumps and serve as a neutral.

6. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
7. Turn the fuel shutoff valve to the OFF position.
8. Loosen both retainers on the sides of the knee pad at least a full rotation until the knee pad is free to lift off.
9. Lift the knee pad straight up and off the machine.
10. Locate the two bypass valves (1) at the rear of the pumps.




Figure 5: Transaxle Bypass Valves Behind Pumps

11. Using a 5/8 inch wrench, rotate the bolt a 1/2 to full turn to allow for proper bypass. Repeat on the other side.
12. Install the knee pad when done.

Tracking Adjustment

The mower is equipped with a hydrostatic transaxle tracking adjustment. Tracking refers to the ability of the mower to travel in a straight line at full forward speed without steering correction. If the mower pulls or drifts to one side during operation, a tracking adjustment is necessary. Before making any adjustments, verify that the tires have been inflated to the proper pressure.

Adjustments should be made to the faster side first. If the mower pulls to the right, adjust the left push rod adjuster. If the mower pulls to the left, adjust the right push rod adjuster.

1. Park the machine on a flat, firm, and level surface, engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Loosen both retainers on the sides of the knee pad at least a full rotation until the knee pad is free to lift off.
4. Lift the knee pad straight up and off the machine.
5. Locate the two push rod adjusters, one on the far left and one on the far right.




Figure 6: Push Rod Adjusters

6. Loosen the two nuts (1).
7. Rotate the push rod adjuster at the knurled section (2) clockwise to shorten the push rod and decrease transaxle speed, or counterclockwise to lengthen the push rod and increase transaxle speed. Make small rotations for minor adjustments.
8. Tighten the two nuts (1).
9. Reinstall the knee pad and tighten the retainers on both sides.

10. Start the mower and drive forward with the control levers fully forward to check if the mower tracks straight. Repeat the procedure as needed.

Pump Belt Adjustment

Over time, the drive belt may stretch or loosen, affecting the performance and responsiveness of the machine. Proper drive belt tension ensures smooth and consistent power transfer to the hydrostatic drive system. If the machine is not responding consistently or the belt appears loose, inspect and adjust the belt tension as needed.

A belt tension gauge provides an accurate reading of the tension.



Figure 7: Belt Tension Gauge

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Using a 3/4 in wrench, loosen the top nut (1).




Figure 8: Pump Belt Spring Tensioner

4. Turn the bottom nut (2) clockwise to increase belt tension or counterclockwise to decrease belt tension.
5. Once the desired tension is achieved, tighten the top nut (1) securely.

6. The tension should be adjusted so that there is between 50-55 lb (23-25 kg) of tension on the belt. Recheck belt tension after 10 minutes.

Engine

Engine Oil

⚠ WARNING

Always clean up spilled flammable fluids or oil. Keep flammable liquids away from heat, flames, sparks, and lighted tobacco. Failure to follow this warning could cause serious injury or death.

An oil drain is installed on the engine to simplify the oil change process. Use Bad Boy 10W-30 synthetic blend engine oil for maximum protection. Bad Boy recommends changing the engine oil and inspecting the oil filter at the intervals specified in the Service Intervals table.

NOTE: Refer to the engine service manual shipped with your machine for additional information on changing the engine oil and replacing the engine oil filter.

⚠ WARNING

Hot oil can cause serious burns. Allow the engine to cool before performing this procedure.

NOTICE

Dispose of used oil in accordance with local, state, and federal regulations.

1. Run the engine to warm.
2. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
3. Turn the fuel shutoff valve to the OFF position.
4. Place an oil collection container beneath the oil drain (1).
5. Remove the cap from the oil drain (1) and direct the hose downward to drain the oil completely.




Figure 9: Oil Drain, Oil Filter, and Oil Location

6. Reinstall the cap on the oil drain (1) securely. If the oil filter (2) is due for replacement, see "Engine Oil Filter" on page 7 before proceeding.
7. Remove the oil dipstick (3) and add new 10W-30 synthetic blend engine oil.
8. Check the oil level. The oil level should reach the upper indicator mark on the dipstick.




Figure 10: Oil Fill Mark

9. Reinstall the oil dipstick (3) and tighten securely.
10. Turn the fuel shutoff valve to the ON position.
11. Start the engine and check for oil leaks.
12. Shut off the engine and remove the ignition key.
13. Recheck the oil level to make sure it is still close to the upper indicator mark.
14. Dispose of used oil and filter in accordance with local ordinances.

Engine Oil Filter

⚠ WARNING

Hot oil can cause serious burns. Allow the engine to cool before performing this procedure.

NOTICE

Dispose of used oil and filter in accordance with local, state, and federal regulations.

1. Position the oil collection container under the oil filter (1).




Figure 11: Engine Oil Filter

2. Remove the oil filter (1) and allow any remaining oil to drain completely.
3. Clean the filter mounting surface on the engine.
4. Prepare and install the new oil filter according to the instructions printed on the filter and in the engine service manual.
5. Return to Step 7 in "Engine Oil" on page 6 to complete the procedure.

Fuel Filter

The fuel filter is located in the fuel line. Always use new fuel line clips.

⚠ WARNING

Gasoline is extremely flammable and the vapors are explosive. Always clean up spilled fuel immediately. Keep flammable liquids away from heat, flames, sparks, and lighted tobacco. Perform service in a well-ventilated area or outdoors. Failure to follow this warning could cause serious injury or death.

NOTICE

Dispose of used fuel filter in accordance with local, state, and federal regulations.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Locate the fuel filter (1) and note the direction of fuel flow as indicated on the filter.




Figure 12: Fuel Filter

4. Clamp the fuel line on both sides of the fuel filter using fuel line clamps (2).
5. Remove the fuel line clips (3) from each side of the fuel filter and remove the fuel filter.
6. Place the new fuel filter in the same direction of fuel flow noted in Step 3.
7. Install new fuel line clips (3) on each side of the fuel filter (1).
8. Remove fuel line clamps (2).
9. Turn the fuel shutoff valve to the ON position.
10. Start the engine to check for fuel leaks.

Air Cleaner

The air cleaner element must be replaced at the interval specified for your engine. Operating the engine with a dirty or damaged air cleaner element can cause loss of power and premature engine failure. Refer to the engine service manual shipped with your machine for recommended replacement interval and additional information specific to your engine.

NOTICE

Do not clean the air cleaner element with compressed air.

⚠ CAUTION

Shut off engine, allow all moving parts to come to a complete stop, and allow to cool before performing service. Failure to follow this warning can cause serious injury or death.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Remove the air cleaner cover (1).




Figure 13: Engine Air Cleaner

4. Remove the pre-cleaner from the air cleaner element (if equipped).
5. Remove the air cleaner element from the air cleaner base.
6. Install the new air cleaner element onto the air cleaner base.
7. Install the pre-cleaner onto the new air cleaner element (if equipped).
8. Reinstall the air cleaner cover (1).

Spark Plug

For spark plug location, specifications and more information, refer to the engine service manual shipped with your machine.

⚠ WARNING

Shut off engine, allow all moving parts to come to a complete stop, and allow to cool before performing service. Failure to follow warning can cause serious injury or death.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Disconnect the spark plug wire from the spark plug.




Figure 14: Spark Plug Location

4. Remove the spark plug using a spark plug socket and ratchet.
5. Inspect the electrode for wear, fouling, or damage.
6. Check the gap against the engine manufacturer's specification. See the engine service manual for gap and torque specifications.




Figure 15: Spark Plug Gap

7. Install the new or gapped spark plug and tighten to the torque specification listed in the engine service manual.
8. Reconnect the spark plug wire.

Electrical System

Inspect all wiring and connectors regularly for chafing, corrosion, or loose fittings. A tight, clean connection at the battery terminals is critical to reliable starting and charging

performance. Replace any wire or connector that shows heat discoloration, cracked insulation, or corrosion buildup.

Fuses

One fuse protect this machine's electrical system:

Fuse	Rating	Location
Main fuse	25A	By the starter solenoid

A blown fuse indicates that excess current has occurred within that circuit, typically due to a fault in the electrical system or a connected component. Do not replace a fuse with one of a higher amperage rating, and do not bypass a fuse under any circumstance. Doing so removes circuit protection and creates a risk of fire or permanent damage to the electrical system. If a fuse blows repeatedly, discontinue use and have the circuit diagnosed before continuing operation.

In order to access the PTO fuse, take off the control panel by removing four control panel screws using an 1/8 in hex bit.

Relay-Controlled Interlocks

The load center contains four relays that govern the safety interlocks controlling machine power-on, drive engagement, and clutch activation. Each relay monitors a specific operator or machine condition; certain functions require confirmation from multiple relays before the corresponding action is permitted. A detailed wiring diagram is available at www.badboycountry.com or by contacting your local Bad Boy dealer.

Starter Signal Solenoid

The starter solenoid requires two conditions to engage and crank the engine: full battery voltage present at its large terminals, and a low-current signal present at its control terminal. The signal originates from the starter relay and instructs the solenoid to close its internal contacts, completing the high-current path from the battery to the starter motor.

If the engine fails to crank and battery voltage tests within specification, verify that the signal wire is fully seated at the starter solenoid's control terminal before replacing the solenoid or starter motor.

Battery

Inspect all wiring, terminals, and connections associated with the battery for damage, corrosion, or looseness prior to service. Battery terminals must remain clean and tight to ensure reliable starting and charging performance. Replace any wiring or connection exhibiting damage, corrosion, or looseness.

Condition	Voltage
Engine running, full throttle	~14 volts DC
Engine off, minimum	12 volts DC

A voltage reading outside these ranges indicates a fault in the charging system or battery condition rather than a wiring fault.

Removal

⚠ CAUTION

Disconnect the negative battery cable before the positive battery cable to prevent electrical arcing. Failure to follow this caution could result in machine damage or personal injury.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Loosen both retainers on the sides of the knee pad at least a full rotation until the knee pad is free to lift off.
4. Lift the knee pad straight up and off the machine. Disconnect the negative battery cable first to prevent electrical arcing.
5. Disconnect the positive battery cable.
6. Remove the battery strap securing the battery to the machine frame.

Installation

⚠ CAUTION

Connect the positive battery cable before the negative battery cable to prevent electrical arcing. Failure to follow this caution could result in machine damage or personal injury.

1. Position the battery in the battery tray.
2. Place the battery strap over the battery to secure the battery to the machine.
3. Connect the positive battery cable.

4. Connect the negative battery cable.
5. Place the knee pad onto the machine.
6. Tighten both retainers on the sides of the podium.

Wheels

Front Caster

The front caster wheel assembly requires periodic inspection and maintenance to ensure proper operation. Inspect the caster wheels for excessive play or wobble before each use.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Inspect the caster wheel for excessive play, wobble, or unusual noise. If any of these conditions are present, the bearing may need to be replaced.
4. To access the caster fork bolt, remove the dust cap (1) by prying gently around its edges using a flat-head screwdriver.




Figure 16: Dust Cap Location

5. Using a 1-7/16 in socket on the caster fork nut (2) and a 1-1/2 in wrench to secure the bolt (3), tighten the caster fork bolt (3) to a torque of 100 ft-lb (135 N·m).




Figure 17: Caster Wheel




Figure 18: Caster Wheel Bolt

6. Reinstall the dust cap (1) by gently tapping around its edges. Do NOT hit the center of the cap.

Wheel Lugs

Torque rear wheel lugs to 65 ft-lb (88 N·m). Retorque at every oil change and before each use.




Figure 19: Rear Wheel Lugs

Lubrication

⚠ WARNING

Never service or maintain machine with engine running. Failure to follow safety precautions can cause serious injury or death.

The machine has the following grease locations and should be greased at every oil change.

	Per	Total
Deck Lift Lever (1)	1	1
Control Actuator Arm, Left and Right (2)	1	2




Figure 20: Grease Locations

Note: NGLI grade #2 multi-purpose gun grease is recommended.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Clean the grease fittings with a cloth. Scrape any dirt/debris off the front face of the fittings.
4. Connect a grease gun to each fitting.
5. Pump grease into the fitting until grease seepage is observed. Be mindful of over-pressurization. Do not force the grease into the component if excessive back pressure is felt as this can lead to reduced life of the component(s).
6. Wipe up any excess grease and dispose of properly.

Cutting Deck

A belt tension gauge provides an accurate reading of the tension.



Figure 21: Belt Tension Gauge

Deck Belt Removal

⚠ CAUTION

Keep fingers and hands away from belt and pulley pinch points. Failure to follow these instructions can cause serious injury.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Raise the deck to the highest position.
4. Remove the pulley covers by loosening the two knobs on each pulley cover.
5. Using a 1/2 in. wrench or socket, loosen the two jam nuts (2) on the deck belt tensioner to relieve belt tension.




Figure 22: Deck Belt Tensioner

6. Lift up on the belt (3) and rotate the pulley (4) by hand until the belt clears the pulley groove.
7. Remove the belt from the remaining pulleys.




Figure 23: Rotating Belt and Pulley

Deck Belt Installation

⚠ CAUTION

Keep fingers and hands away from belt and pulley pinch points. Failure to follow these instructions can cause serious injury.

Important: Improper belt routing can damage the spindles, engine, and increase the potential for personal injury.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Raise the deck to the highest position.
4. Remove the pulley covers by loosening the two knobs on each pulley cover.

5. Route the new belt following the belt route decal on the deck. Confirm the belt is seated in all pulley grooves before proceeding.
6. Using a 3/4 in wrench, adjust the two jam nuts (2) on the deck belt tensioner until belt tension measures 70–75 lb (32–34 kg) with the deck at its lowest cutting height.




Figure 24: Drive Belt Tensioner

7. Install both pulley covers. Tighten each pulley cover to the deck with the two knobs.

Note: When installing a new belt, recheck the belt tension after 10 minutes of cutting time to make sure the tension is between the desired range.

Deck Belt Tension Adjustment

The deck spring tension is critical. If the tension is too high, premature failure of the deck belt and blade spindles can occur. If the tension is too low, the belt can jump off or slip on the pulleys. This results in reduced cut quality and early belt failure.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Using a 3/4 in wrench, adjust the two jam nuts (1) on the deck belt tensioner until belt tension measures 70–75 lb (32–34 kg) with the deck at its lowest cutting height.




Figure 25: Deck Belt Tensioner

Leveling the Deck

⚠ CAUTION

Keep hands and fingers clear of the deck and lift linkage during this procedure. Contact with moving parts can cause serious injury.

Ensure the mower deck is level when there is an uneven cut. The deck should measure 1/4 in higher in the back than in the front from the cutting edge of the blade to the ground for a proper cut.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Turn the fuel shutoff valve to the OFF position.
3. Confirm all tires are inflated to specification.
4. Set the deck height of 3 inches.
5. Lift the chute and rotate the blade so it points front-to-back on the mower.




Figure 26: Direction of Blade

6. At each of the four deck levelers, loosen the slide bolt (1) and the leveler mounting bolt (2).




Figure 27: Slide and Leveler Mounting Bolts, Left Rear

7. With the deck height at 3, measure from the front tip of the blade to the ground. Turn the front right leveler adjustment bolt (3) until this distance reaches 3 in.




Figure 28: Measurement of Ground to Front Tip of Blade

8. Measure from the back tip of the blade to the ground. Turn the back right leveler adjustment bolt (3) until this distance reaches 3-1/4 in — 1/4 in higher than the front, as required for proper cut.
9. Turn the back left leveler adjustment bolt (3) until the left side measures 1/4 in higher than the left front.
10. Recheck all four against the target blade tips measurements. Readjust any leveler adjustment bolt (3) as needed.
11. Once all four measurements hold correct, tighten the slide bolt (1) and leveler mounting bolt (2) at each leveler.

Blade Removal

⚠ WARNING

The use of blades that are not Bad Boy blades can result in blade failure. Blade failure during operation can cause serious injury or death.

NOTICE

The use of unapproved blades may void any or all warranty for both machine and engine.

NOTICE

Use an impact wrench capable of at least 220 ft-lb (298 N•m) output torque to avoid component damage.

⚠ CAUTION

Mower blades are sharp and can cause injury. Wear gloves when handling blades.

1. Park the machine on a flat, firm, and level surface. Engage the parking brake, shut off the engine, and remove the ignition key.
2. Raise the cutting deck to the maximum height.
3. Turn the fuel shutoff valve to the OFF position.
4. Disconnect the battery.
5. Place a piece of wood between the blade and the mowing deck to prevent the blade from turning.
6. Using an impact wrench and 15/16 in. socket, remove the blade bolt from the spindle shaft.

NOTE: The blade bolt has right-handed threads.




Figure 29: Blade Removal

7. Remove the washer and blade from the spindle shaft.

8. Place the new or sharpened blade onto the spindle shaft with the fin or sail facing upward.
9. Install the washer with the cupped side down then install the blade bolt.
10. Tighten the blade bolt to a torque of 110 ft-lb (149 N•m).
11. Confirm the blade rotates freely and orientation matches the previous blade before returning the machine to service.

Decals

Replace damaged or faded safety decals.

1. Clean the area where the label will be placed with soapy water and clean cloth.
2. Spray soapy water on the area again.
3. Peel backing from the label and press the label against the wet surface.
4. Smooth out any air bubbles using a straight edge like a ruler or credit card to create the adhesion to the machine.

SECTION 8

TRANSPORTING

Before transporting the machine, ensure the transport vehicle is suitable to bear the weight of the machine. Weight will fluctuate with the addition of accessories.

Loading

WARNING

Improper fastening during transportation may lead to machine movement and possible loss of load. Failure to follow this warning could cause serious injury or death.

1. Rotate the fuel shutoff valve to the ON position.
2. Set the deck to the maximum height to ensure proper clearance.
3. Start the engine and release the parking brake.
4. Drive the machine onto the trailer in the reverse direction.
5. Center the mower's weight slightly forward of the trailer axles.
6. Engage the parking brake, shut off the engine, and remove the ignition key.
7. Rotate the fuel shutoff valve to the OFF position.

NOTE: Machine securement requirements may vary by state and local regulations. Always comply with all applicable federal, state, and local regulations when transporting this machine on public roads.

8. Attach a strap at the left front and right front of the machine.
9. Attach a strap at the left rear and right rear of the machine.
10. Securely fasten all four straps to the truck or trailer.
11. Secure the ends of the straps.

Unloading

1. Rotate the fuel shutoff valve to the ON position.
2. Set the deck to the maximum height to ensure proper clearance.
3. Start the engine and release the parking brake.
4. Drive the machine forward down the ramps slowly and carefully.
5. Once clear of the ramp, engage the parking brake, shut off the engine, and remove the ignition key.
6. Rotate the fuel shutoff valve to the OFF position.

Moving Inoperable Machine

CAUTION

Never try to push or pull the machine by hand. Failure to follow this caution could cause serious bodily injury.

Do not tow the machine onto a trailer. Use a winch to load the machine onto a trailer for transporting.

1. Turn the fuel shutoff valve to the OFF position.
2. Loosen both retainers on the sides of the knee pad at least a full rotation until the knee pad is free to lift off.
3. Lift the knee pad straight up and off the machine.
4. Locate the two bypass valves (1) at the rear of the pumps.
5. Using a 5/8 inch wrench, rotate the bolt a 1/2 to full turn to allow for proper bypass. Repeat on the other side.
6. Move the machine with the engine off and the bypass rods in the neutral position. Move only as far as necessary.

SECTION 9

WARRANTY

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Bad Boy Mowers, LLC will, at its option, repair or replace, without charge, any part covered by the warranty which is found to be defective in material and/or workmanship for **two (2) years** after the date of sale to the original retail purchaser **unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days.**

- The leading edge of the deck shell will be warranted for the entire **lifetime** of the machine to the original purchaser against defects in materials and workmanship. Labor required to repair or replace the leading edge of the deck shell will be covered by Bad Boy Mowers, LLC for **one (1) year** and at the unit owner's expense during the balance of the lifetime of the machine.
- Belts are warranted for a period of **ninety (90) days** against materials or workmanship defects.
- Knee pads are warranted for a period of **two (2) years** against material or workmanship defects.
- Batteries are warranted for **six (6) months** (free replacement) from the retail purchase date against materials or workmanship defects. The battery warranty must be obtained through the battery manufacturer.

At Bad Boy Mowers, LLC's request, customer will make the defective part available for inspection by Bad Boy Mowers, LLC and/or return the defective part to Bad Boy Mowers, LLC, **transportation charges prepaid.**

2. WHAT THIS WARRANTY DOES NOT COVER:

- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instruction contained in the Owner's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed. **Bad Boy Mowers, LLC will not be responsible for the pickup and delivery of a machine for warranty purposes.**
- C. Engines are warranted separately by their respective manufacturer. The available warranties covering this item are furnished with each mower. Bad Boy Mowers, LLC does not assume any warranty obligation, liability or modification for this item, which is covered exclusively by the stated warranty of the respective manufacturers.
- D. Tires, blades, deck anti-scalping wheels, and dust covers are considered to be consumable wear items and are therefore not warranted.
- E. Normal maintenance services such as oil change, cleaning, lubrication, and adjustments.
- F. Replacement of services and items, such as oil, lubricants, spark plugs, belts, rubber hoses or other items subject to normal service replacement.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

- A. Warranty service can be arranged by contacting the authorized Bad Boy dealer where you purchased your mower or your nearest authorized Bad Boy dealer. Proof of purchase may be required to verify warranty coverage. Warranty repairs must be completed by an authorized Bad Boy dealer.
- B. **Warranty claims will not be reviewed or paid unless the warranty registration is received by Bad Boy Mowers, LLC within 30 days of the retail purchase date.**
- C. Warranty claims requiring parts returned will be settled upon return of parts to Bad Boy for inspection.
- D. All warranty issues must be handled through an authorized service center or dealership.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **BAD BOY MOWERS, LLC WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.

WARRANTY

- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Bad Boy Mowers, LLC, and should not be relied on.
- D. This warranty extends only to turf equipment operated under normal conditions and properly serviced and maintained. The warranty expressly does not cover (i) any defects, damage or deterioration due to normal use, wear and tear, or exposure; (ii) normal maintenance services such as oil change, cleaning, lubrication, adjustment; (iii) replacement of services, items, such as oil, lubricants, spark plugs, belts, rubber hoses or other items subject to normal service replacement; (iv) damage or defects arising out of or relating to misuse, neglect, alteration, negligence or accident; (v) repair or replacement arising from operation of or use of the turf equipment which is not in accordance with operating instructions as specified in the operator's manual or other operational instructions provided by Bad Boy Mowers, LLC; (vi) repair or replacement arising as a result of any operation from turf equipment that has been altered or modified so as to, indetermination of Bad Boy Mowers, LLC, adversely affect the operation, performance or durability of the equipment or that has altered, modified or affected the turf equipment so as to change the intended use of the product; (vii) repair or replacement necessitated by use of parts, accessories or supplies, including gasoline, oil or lubricants, incompatible with the turf equipment or other than as recommended in the operator's manual or other operational instructions provided by Bad Boy Mowers, LLC; (viii) repairs or replacements resulting from parts or accessories which have adversely affected the operation, performance or durability of the turf equipment; or (ix) damage or defects due to or arising out of repair of turf equipment by person or persons other than an authorized Bad Boy Mowers, LLC, service dealer or the installation of parts other than genuine Bad Boy Mowers, LLC, recommended parts. **As a condition to this warranty, customer shall have read the operator's manual and ensured the mower has been registered within 30 days of purchase.**
- E. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

1.



BAD BOY MOWERS

www.badboycountry.com

Bad Boy, Inc.

102 Industrial Drive

Batesville, Arkansas 72501